

ExactLogic BACnet Communicating Thermostat

MUA analog cooling only with Outside Air Reset for discharge air temperature Control

EXL01815 Sequence Datasheet



BACnet is a registered trademark of ASHRAE. ASHRAE does not endorse, approve or test products for compliance with ASHRAE standards. Compliance of listed products to requirements of ASHRAE Standard 135 is the responsibility of the BACnet International. BTL is a registered trademark of the BACnet International.



DataSheet Rev 1.12.307/4.0

June 21, 2018

Operating Sequence

Standard Occupied

During normal occupied operation the display will show the current room temperature. The first press of either right pair of keys will show the current room setpoint. Additional presses will adjust the setpoint up or down by 0.5 degrees. The thermostat keypad will time out after 5 seconds without a key press, and the display will switch back to displaying the room temperature.

The left pair of keys allows for the adjustment of the fan speed. The current mode is shown with the first key press; additional key presses will show the adjustment to the mode. AV-62 is used to select the number of fan speeds, and AV-63 will show what speed the fan is currently set to. Refer to the table below for the values of AV-62 (Fan Mode Status) and AV-63 (Fan Speed Status)

| AV-62 | Mode |
|-------|----------------|
| 0 | AUTO Only |
| 1 | AUTO-ON |
| 2 | OFF-AUTO-ON |
| 3 | OFF-1-2-AUTO |
| 4 | OFF-1-2-3-AUTO |

| AV-63 | Fan Speed |
|-------|-------------|
| 0 | OFF |
| 1 | Fan Speed 1 |
| 2 | Fan Speed 2 |
| 3 | Fan Speed 3 |
| 4 | AUTO |
| 5 | ON |

Control Sequence - Fan

The fan is commanded ON when occupied, in cooldown or warmup. The fan will be overridden off by a Unit Disable command at BV-66.

Control Sequence – Supply Temperature Reset

There are multiple modes that the Supply Temperature can command to.

Warmup Mode

If the unit is commanded to be in a Warmup Mode (BV-41 = ACTIVE), The Supply Air Temperature SP (AV-3) will be set to the Warmup Setpoint (AV-52).

Manual Mode

The Supply Air Temperature SP can be set to a manual setpoint. By setting BV-50 = INACTIVE, AV-3 will be set to the value of AV-51. AV-3 will not be able to change values until BV-50 is set to ACTIVE (Auto Mode).

Auto Mode

Auto Mode is set by commanding BV-50 to ACTIVE. When in this mode there is always a 5 minute Startup delay. The Supply Air Temperature SP (AV-3) will be commanded to the value of AV-51 whenever the Supply Fan Command (BO-0) changes from an INACTIVE state to ACTIVE for 5 minutes. After the 5 minutes, AV-3 will be set to the calculated setpoint determined by the outside air temperature (AI-5). The supply temperature setpoint will reset between the valves of AV-47/48 with the outside air temperature reset setpoints at AV-45/46.

Control Sequence –Cooling

The cooling valve is commanded by a 0-10VDC modulating signal at AO-0. The maximum and minimum output voltage can be scaled by using AV42/43. The cooling valve modulating signal is controlled by a 0-100% PI calculated feedback



HumeraTech is the exclusive U.S. distributor for ExactLogic products

14295 James Rd. Suite #200 | Rogers, MN | 55374

1-866-714-0522 | www.exactlogic.com

signal shown at AV-15. The control signal is calculated using the discharge air temperature (AI-4) and discharge air setpoint (AV-3).

The cooling valve command can be locked out by outside air setpoint (AV-41), a low limit alarm (BV-21), or by a warmup command (BV-41).

Standard Unoccupied

During unoccupied operation the thermostat will continue to display the room temperature. When in an unoccupied state pressing one of the right pair of keys will display a message indicating the thermostat is in night mode, preventing the setpoint from being adjusted. To adjust the room setpoint when unoccupied the thermostat must be set to night override.

Control Sequence

When in the unoccupied mode, the room will be controlled by the unoccupied cooling/heating setpoints. The fan and cooling/heating stages will operate the same as the occupied control sequence.

Vacancy

If a room is known to be vacant, vacant setpoints can be used to override the unoccupied setpoints. By setting BV-70, a room will be controlled by the vacant cooling/heating setpoints (AV-64/65).

Night Override

Set the night override by pressing one of the left pair of keys. The display will switch to allow the user to set the night override time. Additional presses of the keys will adjust the time up or down by 0.5 hour increments. The night override can be increased up to the override limit set at AV-73, the default is 5 hours. When the thermostat is in night override, the first press of one of the left pair of keys will display the override time remaining. Additional key presses will add/subtract 0.5 hours to the time that was remaining. When the timer reaches zero the thermostat will return to the unoccupied mode.

In the night override mode, the right pair of keys can be used to adjust the room setpoint. The thermostat keypad will time out after 5 seconds without a key press, and the display will switch back to displaying the room temperature.

The thermostat can be set to a night override by writing a value to AV-74 through BACnet. The value can not exceed the night override limit set at AV-73. If the night override time is set higher than the limit, the night override timer will be set to the limit. The night override limit default is 5 hours.

If the thermostat is commanded to the occupied mode while in night override, the override timer will be cleared to zero and the thermostat will enter the occupied mode.

Control Sequence

When the thermostat is in the override mode, the room will be controlled by the occupied cooling/heating setpoints. The fan and cooling/heating stages will operate the same as the occupied control sequence.

Note: There is no fan control in the override mode. The fan will run in the AUTO mode.

Vacancy

If a room is known to be vacant, vacant setpoints can be used to override the unoccupied setpoints. By setting BV-70 to active, a room will be controlled by the vacant cooling/heating setpoints (AV-64/65).

Motion/Humidity Option Card

The Motion/Humidity Option Card can be used for Motion Only, Humidity Only, or Motion/Humidity together. In order to use the Motion Sensor (either stand alone or with Humidity), BV-64 must be set to ACTIVE. The Humidity Sensor can be enabled by setting AV-31 to 4. These settings will automatically provide the required voltage to power the sensors. The motion sensor status will show on BI-1.

When the motion sensor, senses motion, it puts the unit in occupied “Active” Mode by writing to the Scheduled Occupied Command BO-5 at priority array entry 11, this will remain active until it does not see any motion for the entire duration of the time delay (AV-81 Units=seconds), it will then return to an inactive state.

When the internal occupancy sensor is enabled by setting BV-64 to ACTIVE, the occupied mode is controlled only by the occupancy sensor. The optimum start warmup point, BV-41, and optimum start cooldown point, BV-42, will set the unit to the occupied mode and then return to the unoccupied mode until motion is sensed.

The Humidity value is shown on AI-1. The Humidity Sensor will automatically be scaled by setting AV-31 to 4.

Disabling of the Splash, Setup Menu, or Field Service Mode

When the thermostat is installed in a public location there may be times when the setup of the thermostat will need to be disabled to prevent tenants from changing the configuration while still giving them access to change the setpoints and control after hours modes. The following points have been added to allow this:

- BV-57 = Setting ACTIVE will disable the “EXACTLOGIC” splash display after key presses
- BV-58 = Setting ACTIVE will disable access to the Setup Menu where the Network/MAC/Baud Rate/etc are set
- BV-59 = Setting ACTIVE will disable access to the Field Service Mode where Time/Schedule/Setpoints/etc are set

Installation




Fig. 4

*Note: Thermostat Common Relay point (BO Hot) usually 24VAC/DC or R

AC 24V 24VAC/DC Hot
 GND Neutral/Ground
 GND Neutral/Ground
 UI2 Universal Input 2
 UI3 Universal Input 3
 UI4 Universal Input 4
 UI5 Universal Input 5
 GND Neutral/Ground
 Comm (+) Network Positive Line
 Comm (-) Network Negative Line
 BO Hot Com, 24VAC Hot for relays*
 BO4 Relay 5 Output, 24VAC/DC
 BO3 Relay 4 Output, 24VAC/DC
 BO2 Relay 3 Output, 24VAC/DC
 BO1 Relay 2 Output, 24VAC/DC
 BO0 Relay 1 Output, 24VAC/DC
 AO1 Analog Output 1, 0-10V
 AO0 Analog Output 0, 0-10V

1 Neutral/Ground
 2 Universal Input 1
 3 Analog Output 2
 4 Reserved

Output Wiring

| Output/Label | |
|--------------|-------------------------|
| BO0 | Fan |
| BO1 | |
| BO2 | |
| BO3 | |
| BO4 | |
| AO0 | Cooling 0-10 Vdc 0-100% |
| AO1 | |

Reserved BACnet Points

The following are points reserved by the thermostat for operation.

Analog Inputs

| Instance | Object Name | Description | Read/Write | Default |
|----------|------------------|--|------------|----------|
| AI-0 | Room Temp | Reading of the internal thermistor in counts. 0-1024 | R | variable |
| AI-1 | Humidity | Reading from the Humidity sensor add-on card | R | variable |
| AI-2 | Analog Input 02 | Reading of the external input 2 in counts. 0-1024 | R | variable |
| AI-3 | Analog Input 03 | Reading of the external input 3 in counts. 0-1024 | R | variable |
| AI-4 | Supply Air Temp | Supply Air Temperature sensor input | R | variable |
| AI-5 | Outside Air Temp | Outside Air Temperature sensor input | R | variable |

Analog Outputs

| Instance | Object Name | Description | Read/Write | Default |
|----------|-----------------|---|------------|---------|
| AO-0 | Cooling Valve | 0-10V output for control of the cooling valve | R/W | 0.0 |
| AO-1 | Analog Output 1 | | R/W | 0.0 |
| AO-2 | Analog Output 2 | Variable 0-14VDC, 150mA output | R/W | 0.0 |

Analog Values

| Instance | Object Name | Description | Read/Write | Default |
|----------|----------------------------|--|------------|---------|
| AV-0 | Mode of Operation | The mode that the thermostat is currently in. 0 = Heat Mode 1 = Cool Mode 2 = Idle 3 = Afterhours 4 = Unoccupied Idle 5 = Unoccupied Heat Mode 6 = Unoccupied Cool Mode | R | 4 |
| AV-1 | Analog Value 001 | | | |
| AV-2 | Analog Value 002 | | | |
| AV-3 | Current Supply Air Temp SP | Current Supply Air Temperature Setpoint based from the reset schedule (AV47/48) | R | varies |
| AV-4 | Analog Value 004 | | | |
| AV-5 | Analog Value 005 | | | |
| AV-6 | Analog Value 006 | | | |
| AV-7 | Analog Value 007 | | | |
| AV-8 | Analog Value 008 | | | |
| AV-9 | Analog Value 009 | | | |
| AV-10 | Analog Value 010 | | | |
| AV-11 | Analog Value 011 | | | |
| AV-12 | Analog Value 012 | | | |
| AV-13 | Analog Value 013 | | | |
| AV-14 | Analog Value 014 | | | |

| | | | | |
|-------|----------------------------|--|-----|------|
| AV-15 | Supply Temp Control Signal | 0-100 feedback control signal used to control the cooling valve | R | 0% |
| AV-16 | Analog Value 016 | | | |
| AV-17 | Cooling Valve Position | Estimated position of the cooling valve | R | 0% |
| AV-18 | Analog Value 018 | | | |
| AV-19 | Analog Value 019 | | | |
| AV-20 | Reserved | This point is reserved for internal thermostat use and its value cannot be changed | R | 0 |
| AV-21 | Analog Value 021 | | | |
| AV-22 | Analog Value 022 | | | |
| AV-23 | Analog Value 023 | | | |
| AV-24 | Analog Value 024 | | | |
| AV-25 | Analog Value 025 | | | |
| AV-26 | Analog Value 026 | | | |
| AV-27 | Analog Value 026 | | | |
| AV-28 | Analog Value 028 | | | |
| AV-29 | Analog Value 029 | | | |
| AV-30 | AI-0 Setup | Parameter used to set the input type. 0 = counts 1 = temperature 2 = 4-20mA 3 = 0-5V 4 = 0-10V 5 = pulse | R/W | 1 |
| AV-31 | AI-1 Setup | See AV-30 | R/W | 0 |
| AV-32 | AI-2 Setup | See AV-30 | R/W | 0 |
| AV-33 | AI-3 Setup | See AV-30 | R/W | 0 |
| AV-34 | AI-4 Setup | See AV-30 | R/W | 0 |
| AV-35 | AI-5 Setup | See AV-30 | R/W | 0 |
| AV-36 | Supply Air Low Limit SP | The lowest Supply Air Temperature allowed before triggering and alarm (BV-21) | R/W | 45°F |
| AV-37 | Analog Value 037 | | | |
| AV-38 | Analog Value 038 | | | |
| AV-39 | Analog Value 039 | | | |
| AV-40 | Analog Value 040 | | | |
| AV-41 | Cooling Lockout SP | When the Outside Air Temperature is below this setpoint, cooling is locked out | R/W | 55°F |
| AV-42 | Cooling Valve Min Output | The minimum output voltage used to command the cooling valve (x10) | R/W | 0 |
| AV-43 | Cooling Valve Max Output | The maximum output voltage used to command the cooling valve (x10) | R/W | 100 |
| AV-44 | Supply Air Deviation DB | Amount the Supply Air Temperature is allowed to be from SP (+/-) before triggering an alarm (BV-23) | R/W | 10°F |
| AV-45 | Outside Air Low SP | The low setpoint for the Outside Air Temperature SP reset schedule | R/W | 60°F |
| AV-46 | Outside Air High SP | The high setpoint for the Outside Air Temperature SP reset schedule | R/W | 80°F |
| AV-47 | Supply Air Low SP | The low setpoint for the Supply Air Temperature SP reset schedule | R/W | 55°F |
| AV-48 | Supply Air High SP | The high setpoint for the Supply Air Temperature SP reset schedule | R/W | 70°F |

| | | | | |
|--------|------------------------------|--|-----|----------|
| AV-49 | Analog Value 049 | | | |
| AV-50 | Analog Value 050 | | | |
| AV-51 | Supply Air SP Manual/Startup | The Supply Air Temperature SP when the unit is in Startup or the reset schedule is in Manual (BV-50) | R/W | 75°F |
| AV-52 | Supply Air SP Warmup | The Supply Air Temperature when the unit is in Warmup Mode | R/W | 85°F |
| AV-53 | Analog Value 053 | | | |
| AV-54 | Analog Value 054 | | | |
| AV-55 | Filter Alarm SP | Maximum runtime for the filter before triggering an alarm (BV-25). | R/W | 3000 hrs |
| AV-56 | Filter Runtime | The number of runtime hours on the filter. Set to zero (0) after changing filter. | R/W | 0 hrs |
| AV -57 | Supply Fan Runtime | The number of runtime hours on the fan. | R/W | 0 hrs |
| AV-58 | Reserved | This point is reserved for internal thermostat use and its value cannot be changed | R | 1.6 |
| AV-59 | Avg Time Base | Factor used to average the room temperature. A small number will allow the room temperature to change faster over time. A large number will cause the room temperature to change slower over time. | R | 100 |
| AV-60 | Calibration Offset | The calibration offset for the internal thermistor. | R | variable |
| AV-61 | Space Alarm Offset | This offset +/- the Current Cooling/Heating SP is used to determine if the space is too warm/cold, and set an alarm if necessary. | R/W | 5.0°F |
| AV-62 | # of Fan Speeds | Select the number of fan speeds for a multispeed fan. 0 = Auto Only 1 = AUTO - ON 2 = Off - AUTO - ON 3 = Off-1-2-AUTO 4 = Off-1-2-3-AUTO | R/W | 0 |
| AV-63 | Current Fan Speed | The fan speed the thermostat is currently running. 0 = OFF 1 = Fan Speed 1 2 = Fan Speed 2 3 = Fan Speed 3 4 = AUTO 5 = ON | R | 4 |
| AV-64 | Vacant Clg SP | Used in Hotel Mode. When a room is known vacant, the setpoint can be set below the unoccupied setpoint. | R/W | 85.0°F |
| AV-65 | Vacant Htg SP | Used in Hotel Mode. When a room is known vacant, the setpoint can be set below the unoccupied setpoint. | R/W | 55.0°F |
| AV-66 | Room Setpoint | The occupied room setpoint | R/W | 73.0°F |
| AV-67 | Occupied SP Hi Limit | The maximum occupied room setpoint allowed. | R/W | 85.0°F |
| AV-68 | Occupied SP Lo Limit | The minimum occupied room setpoint allowed | R/W | 55.0°F |
| AV-69 | Clg Offset | The offset from Room Setpoint used to calculate the Occupied Cooling SP | R/W | 1.0°F |

| | | | | |
|--------|-------------------|--|-----|----------|
| AV-70 | Htg Offset | The offset from Room Setpoint used to calculate the Occupied Heating SP | R/W | 1.0°F |
| AV-71 | Unoccupied Clg SP | The cooling setpoint used when the thermostat is unoccupied. | R/W | 80.0°F |
| AV-72 | Unoccupied Htg SP | The heating setpoint used when the thermostat is unoccupied. | R/W | 60.0°F |
| AV-73 | After Hours Limit | The maximum hours the thermostat is allowed to run during afterhours time. Setting this will set the thermostat to occupied operation. (0-99.9 hrs) | R/W | 5.0 hrs |
| AV-74 | After Hours Timer | The current amount of afterhours time left. | R | 0.0 hrs |
| AV-75 | Reserved | This point is reserved for internal thermostat use and its value cannot be changed | R | 0 |
| AV-76 | Reserved | This point is reserved for internal thermostat use and its value cannot be changed | R | 0 |
| AV-77 | Reserved | This point is reserved for internal thermostat use and its value cannot be changed | R | 0 |
| AV-78 | Reserved | This point is reserved for internal thermostat use and its value cannot be changed | R | 0 |
| AV-79 | Reserved | This point is reserved for internal thermostat use and its value cannot be changed | R | 0 |
| AV-80 | Reserved | This point is reserved for internal thermostat use and its value cannot be changed | R | 0 |
| AV-81 | Motion OFF Delay | The amount of time to delay the ON->OFF transition of the motion sensor occupied command after no motion is detected | R/W | 900 sec |
| AV-82 | Analog Value 082 | | | |
| AV-83 | Analog Value 083 | | | |
| AV-84 | Analog Value 084 | | | |
| AV-100 | Analog Value 100 | Internal thermistor display descriptor. The present value is automatically transferred. The AV description holds the descriptor to display. | R | variable |
| AV-101 | Analog Value 101 | Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display. | R/W | |
| AV-102 | Analog Value 102 | Discharge Air display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display | R/W | |
| AV-103 | Analog Value 103 | Cooling Valve Position display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display | R/W | |
| AV-104 | Analog Value 104 | Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display | R/W | |
| AV-105 | Analog Value 105 | Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display | R/W | |
| AV-106 | Analog Value 106 | Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display | R/W | |
| AV-107 | Analog Value 107 | Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display | R/W | |

| | | | | |
|--------|------------------|---|-----|--|
| AV-108 | Analog Value 108 | Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display | R/W | |
| AV-109 | Analog Value 109 | Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display | R/W | |
| AV-110 | Analog Value 110 | Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display | R/W | |
| AV-111 | Analog Value 111 | Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display | R/W | |
| AV-112 | Analog Value 112 | Outside Air Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display | R/W | |

Binary Inputs

| Instance | Object Name | Description | Read/Write | Default |
|----------|-----------------|---|------------|---------|
| BI-0 | Binary Input 00 | | R | |
| BI-1 | Motion | Motion sensor status from the add-on card | R | |
| BI-2 | Binary Input 02 | | R | |
| BI-3 | Binary Input 03 | | | |
| BI-4 | Binary Input 04 | | R | |
| BI-5 | Binary Input 05 | | | |

Binary Outputs

| Instance | Object Name | Description | Read/Write | Default |
|----------|--------------------|---|------------|---------|
| BO-0 | Fan | Output for Fan Control | R/W | OFF |
| BO-1 | Binary Output 01 | | | |
| BO-2 | Binary Output 02 | | | |
| BO-3 | Binary Output 03 | | | |
| BO-4 | Binary Output 04 | | | |
| BO-5 | Scheduled Occupied | Logical point only. Used for scheduling purposes. INACTIVE is unoccupied. | R/W | OFF |

Binary Values

| Instance | Object Name | Description | Read/Write | Default |
|----------|------------------------|--|------------|---------|
| BV-0 | Binary Value 000 | | | |
| BV-1 | Binary Value 001 | | | |
| BV-2 | Binary Value 002 | | | |
| BV-3 | Binary Value 003 | | | |
| BV-4 | Binary Value 004 | | | |
| BV-5 | Binary Value 005 | | | |
| BV-6 | Binary Value 006 | | | |
| BV-7 | Binary Value 007 | | | |
| BV-8 | Binary Value 008 | | | |
| BV-9 | Binary Value 009 | | | |
| BV-10 | Program Status | Used to determine if the sequence was loaded correctly on a BACnet Restore or power up. | R | OFF |
| BV-11 | Binary Value 011 | | | |
| BV-12 | Binary Value 012 | | | |
| BV-13 | Binary Value 013 | | | |
| BV-14 | Binary Value 014 | | | |
| BV-15 | 5 Minute Startup Delay | This delay commands the Supply Air SP to the Manual/Startup SP (AV-51) for 5 minutes after the supply fan starts | R | OFF |
| BV-16 | Binary Value 016 | | | |
| BV-17 | Binary Value 017 | | | |
| BV-18 | Binary Value 018 | | | |
| BV-19 | Binary Value 019 | | | |
| BV-20 | Unit Alarm | An alarm on BV-21, 23, or 25 has been triggered | R | OFF |

| | | | | |
|-------|--------------------------------|---|-----|-----|
| BV-21 | Low Limit Alarm | The Supply Air Temperature is too low | R | OFF |
| BV-22 | Binary Value 022 | | | |
| BV-23 | Supply Deviation Alarm | The Supply Air Temperature (AI-4) is +/- AV-43 degrees from the current Supply Air SP (AV-3) | R | OFF |
| BV-24 | Binary Value 024 | | | |
| BV-25 | Filter Alarm | The filter runtime is over the setpoint hours | R | OFF |
| BV-26 | Binary Value 026 | | | |
| BV-27 | Binary Value 027 | | | |
| BV-28 | Binary Value 028 | | | |
| BV-29 | Binary Value 029 | | | |
| BV-30 | Unit Alarm Reset | Reset the status of BV-20 | R/W | OFF |
| BV-31 | Low Limit Alarm Reset | Reset the low Supply Air Temperature alarm status | R/W | OFF |
| BV-32 | Binary Value 032 | | | |
| BV-33 | Binary Value 033 | | | |
| BV-34 | Binary Value 034 | | | |
| BV-35 | Binary Value 035 | | | |
| BV-36 | Binary Value 036 | | | |
| BV-37 | Binary Value 037 | | | |
| BV-38 | Binary Value 038 | | | |
| BV-39 | Cooling Enable | Indicated whether cooling has been locked out due to Outside Air Temperature (OFF = Locked Out) | R | ON |
| BV-40 | Occupied Status | The status of this point switches the thermostats occupancy settings. When ON, the thermostat is in Occupied Setpoint Mode or After Hours Mode. | R | OFF |
| BV-41 | Opt. Start Warmup | A Warmup command has been sent to the thermostat. When ON the thermostat will switch to occupied settings. | R/W | OFF |
| BV-42 | Opt. Start Cooldown | A Cooldown command has been sent to the thermostat. When ON the thermostat will switch to occupied settings. | R/W | OFF |
| BV-43 | Occ Set point Mode | The thermostat has been commanded occupied via BO-5, or a Warmup/Cooldown command has been sent via BV-41/BV-42. | R | OFF |
| BV-44 | After Hours Status | The thermostat has been set to afterhours mode. When ON the thermostat will switch to occupied settings. | R | OFF |
| BV-45 | Reserved | This point is reserved for internal thermostat use and its value cannot be changed | R | OFF |
| BV-46 | Binary Value 046 | | | |
| BV-47 | Binary Value 047 | | | |
| BV-48 | Binary Value 048 | | | |
| BV-49 | Update Descriptors | When ON descriptor changes are sent to the thermostats LCD, this point will auto reset to OFF. | R/W | OFF |
| BV-50 | Supply Air Temperature SP Mode | OFF = Manual Setpoint ON = Auto calculated setpoint | R/W | ON |
| BV-51 | Binary Value 051 | | | |
| BV-52 | Binary Value 052 | | | |
| BV-53 | Binary Value 053 | | | |

| | | | | |
|--------|--------------------|---|-----|-----|
| BV-54 | Binary Value 054 | | | |
| BV-55 | Binary Value 055 | | | |
| BV-56 | Binary Value 056 | | | |
| BV-57 | Disable Splash | When ACTIVE, the "EXACTLOGIC" splash will not show after key presses | R/W | OFF |
| BV-58 | Disable Setup Menu | When ACTIVE, there will be no access to the Setup Menu where the Network/MAC/Baud Rate is set | R/W | OFF |
| BV-59 | Disable FSM Menu | When ACTIVE, there will be not access to the Field Service Mode where the Time/Schedule/Point Access is set | R/W | OFF |
| BV-60 | Binary Value 060 | | | |
| BV-61 | Binary Value 061 | | | |
| BV-62 | Binary Value 062 | | | |
| BV-63 | Binary Value 063 | | | |
| BV-64 | Enable Motion | When ACTIVE, the power to the Motion add-on card is set to the proper voltage | R/W | OFF |
| BV-65 | Binary Value 065 | | | |
| BV-66 | Disable Unit | When ON this point will disable and lockout all analog and binary outputs. | R/W | OFF |
| BV-67 | Binary Value 067 | | | |
| BV-68 | Backlight Off/On | When ON the LCD backlight will remain on | R/W | OFF |
| BV-69 | Binary Value 069 | | | |
| BV-70 | Room Vacant Status | When ON the thermostat will run on Vacant Heating/Cooling setpoints, AV-64/AV-65. | R/W | OFF |
| BV-71 | C/F | Sets the thermostat to display temperatures in Celsius or Fahrenheit. This point is set through the setup menu. ON = F, OFF = C | R | ON |
| BV-72 | Binary Value 072 | | | |
| BV-73 | Binary Value 073 | | | |
| BV-74 | Hotel Mode | This point is reserved for internal thermostat use and its value cannot be changed | R/W | OFF |
| | | | | |
| BV-100 | Binary Value 100 | Enable internal thermistor descriptor | R/W | OFF |
| BV-101 | Binary Value 101 | Enable descriptor | R/W | OFF |
| BV-102 | Binary Value 102 | Enable discharge air descriptor | R/W | ON |
| BV-103 | Binary Value 103 | Enable cooling valve position descriptor | R/W | ON |
| BV-104 | Binary Value 104 | Enable descriptor | R/W | OFF |
| BV-105 | Binary Value 105 | Enable descriptor | R/W | OFF |
| BV-106 | Binary Value 106 | Enable descriptor | R/W | OFF |
| BV-107 | Binary Value 107 | Enable descriptor | R/W | OFF |
| BV-108 | Binary Value 108 | Enable descriptor | R/W | OFF |
| BV-109 | Binary Value 109 | Enable descriptor | R/W | OFF |
| BV-110 | Binary Value 110 | Enable descriptor | R/W | OFF |
| BV-111 | Binary Value 111 | Enable descriptor | R/W | OFF |
| BV-112 | Binary Value 112 | Enable outside air descriptor | R/W | ON |