

ExactLogic BACnet Communicating Thermostat EXL01680 Sequence Datasheet

Lead Lag Pump Control



BACnet is a registered trademark of ASHRAE. ASHRAE does not endorse, approve or test products for compliance with ASHRAE standards. Compliance of listed products to requirements of ASHRAE Standard 135 is the responsibility of the BACnet International. BTL is a registered trademark of the BACnet International.



DataSheet Rev 1.20.001/5.0
October 9, 2023

Operating Sequence

Internal/External Thermistor Control

The thermostat control sequence can use the internal thermistor or an external thermistor connected to AI-2. Setting BV-67 to OFF (default) the thermostat will use the internal thermistor. Setting BV-67 to ON the control sequence will use the external thermistor.

The current controlling temperature is located at AV-20. This value will be displayed on the LCD of the thermostat and should be used on any workstation displays.

Control Sequence – Pump Enable

The pumps are enabled via Outside Air Enable Set point (AV-57). When the outside air temperature drops below this setpoint the pumps are enabled.

Control Sequence – Pump Runtime Switch

The lead/lag pumps can be configured to switch by day (24hours), week (168 hours), month (720 hours), or custom runtime hours. The selection is done via BV-60 through BV-62. If none of the BV's are selected BV-63 is selected automatically for custom runtime hours. The custom runtime hours is configured at AV-45, and defaulted to 336 hours.

The lead/lag pumps can also be switched manually via BV-26.

Control Sequence – Pump VFD Controls

VFD signals for pump control are found at AO-0 for P-1 and AO-1 for P-2. The modulating signal is calculated using the pressure Setpoint (AV-55) and the Pressure Input (AI-5). If there is no pump status on P-1 or P-2 the corresponding AO will be disabled.

Control Sequence – Pump Alarms

The pump alarm/status is determined by a current sensor for each pump, AI-3 for P-1 and AI_4 for P-2. Pump alarms are determined by HI/Lo alarm setpoint for each pump, P-1 Hi/Lo setpoints are at AV-51/50 and P-2 Hi/Lo setpoints are at AV-53/52.

Installation




Fig. 4

*Note: Thermostat Common Relay point (BO Hot) usually 24VAC/DC or R

*Note: AI-2 through AI-5 and BI-2 through BI-5 are wired to UI-2 through UI-5. Each universal Input can only be used as an AI or a BI

GND Neutral/Ground
 UI-2 Universal Input 2
 UI-3 Universal Input 3
 UI-4 Universal Input 4
 UI-5 Universal Input 5
 UI-6 Universal Input 6
 UI-7 Universal Input 7
 UI-8 Universal Input 8
 UI-9 Universal Input 9
 UI-10 Universal Input 10
 UI-11 Universal Input 11
 UI-12 Universal Input 12
 UI-13 Universal Input 13
 MSTP + Network Line Positive
 MSTP - Network Line Negative

BO Hot 24VAC/DC Input for Relays 1-5*
 BO-0..... Relay 1 Output, 24VAC/DC
 BO-1..... Relay 2 Output, 24VAC/DC
 BO-2..... Relay 3 Output, 24VAC/DC
 BO-3..... Relay 4 Output, 24VAC/DC
 BO-4..... Relay 5 Output, 24VAC/DC
 BO Hot 2 24VAC/DC Input for Relays 7-9*
 BO-6..... Relay 7 Output, 24VAC/DC
 BO-7..... Relay 8 Output, 24VAC/DC
 BO-8..... Relay 9 Output, 24VAC/DC
 GND Neutral/Ground
 AO-0..... Analog Output 0, 0-10V
 AO-1..... Analog Output 1, 0-10V
 AO-2..... Analog Output 2, 0-10V
 AO-3..... Analog Output 3, 0-10V

GND Neutral/Ground
 GND Neutral/Ground
 GND Neutral/Ground
 PSOut 24VAC/DC Hot
 PSOut 24VAC/DC Hot
 PSOut 24VAC/DC Hot
 Power - Neutral/Ground
 Power + 24VAC/DC Hot

GND Neutral/Ground
 AO-04..... Analog Output 4, 0-10V
 AO-05..... Analog Output 5, 0-10V
 AO-06..... Analog Output 6, 0-10V
 AO-07..... Analog Output 7, 0-10V
 +19Vdc..... 19V DC
 GND Neutral/Ground

Output Wiring

Output/Label	Function
BO0	P-1 Command
BO1	P-2 Command
BO2	
BO3	
BO4	
AO0	P-1 VFD Signal
AO1	P-2 VFD Signal

Reserved BACnet Points

The following are points reserved by the thermostat for operation.

Analog Inputs

Instance	Object Name	Description	Read/Write	Default
AI-0	Room Temp	Reading of the internal thermistor.	R	variable
AI-1	Analog Input 01	Reading of the external input 1.	R	variable
AI-2	Supply Pres/Ext Temp	Used for 2 Pressure Sensor Applications (Supply/Return) for Differential Pressure Calculation or a custom Universal Input	R	variable
AI-3	Core Pump 1 Amps	Reading of P-1 pump amps	R	variable
AI-4	Core Pump 2 Amps	Reading of P-2 pump amps	R	variable
AI-5	Diff Press/Ret Pres	With only 1 Differential Pressure Sensor (wire here) With 2 Pres. Sensors (Wire Return Pressure Here)	R	variable

Analog Outputs

Instance	Object Name	Description	Read/Write	Default
AO-0	P-1 VFD Command	0-10V output for control of P-1 VFD signal	R/W	0.0
AO-1	P-2 VFD Command	0-10V output for control of P-2 VFD signal	R/W	0.0
AO-2	Analog Output 2	Variable 0-14VDC, 150mA output	R/W	0.0

Analog Values

Instance	Object Name	Description	Read/Write	Default
AV-0	Mode of Operation	The mode that the thermostat is currently in. 0 = Heat Mode 1 = Cool Mode 2 = Idle 3 = Afterhours 4 = Unoccupied Idle 5 = Unoccupied Heat Mode 6 = Unoccupied Cool Mode	R	4

AV-1	Analog Value 001			
AV-2	Analog Value 002			
AV-3	Analog Value 003			
AV-4	Reserved	This point is reserved for internal thermostat use and its value cannot be changed		
AV-5	Reserved	This point is reserved for internal thermostat use and its value cannot be changed		
AV-6	Reserved	This point is reserved for internal thermostat use and its value cannot be changed		
AV-7	Reserved	This point is reserved for internal thermostat use and its value cannot be changed		
AV-8	Analog Value 008			
AV-9	Analog Value 009			
AV-10	P-1 Cycle Time Status	Amount of runtime that P-1 has completed for the current cycle in hours	R	0
AV-11	P-1 Cycle Setpoint	Current Cycle Time Limit. Once the runtime reaches this setpoint a Runtime Lead/Lag Switch will be triggered.	R	0
AV-12	P-2 Cycle Time Status	Amount of runtime that P-2 has completed for the current cycle in hours	R	0
AV-13	P-2 Cycle Setpoint	Current Cycle Time Limit. Once the runtime reaches this setpoint a Runtime Lead/Lag Switch will be triggered.	R	0
AV-14	Analog Value 014			
AV-15	Differential Pres.	Differential Pressure Reading	R	Variable
AV-16	Analog Value 016			
AV-17	Analog Value 017			
AV-18	Analog Value 018			
AV-19	Analog Value 019			
AV-20	Room Temp	Selected from either AI-0 or AI-2. BV-67 is used for selection. This is the value displayed on the LCD of the thermostat and should be used to display the temperature on any workstation display.	R	variable
AV-21	Analog Value 021			
AV-22	Analog Value 022			
AV-23	Analog Value 023			
AV-24	Analog Value 024			
AV-25	P-1 VFD Signal	VFD signal for pump 1, as a percentage	R	0%
AV-26	P-2 VFD Signal	VFD signal for pump 2, as a percentage	R	0%
AV-27	Analog Value 027			
AV-28	Analog Value 028			
AV-29	Analog Value 029			
AV-30	AI-0 Setup	Parameter used to set the input type. 0 = counts 1 = temperature 2 = 4-20mA 3 = 0-5V 4 = 0-10V 5 = pulse	R	1
AV-31	AI-1 Setup	See AV-30	R	0
AV-32	AI-2 Setup	See AV-30	R	0
AV-33	AI-3 Setup	See AV-30	R	0
AV-34	AI-4 Setup	See AV-30	R	0
AV-35	AI-5 Setup	See AV-30	R	0

AV-36	P-1 VFD Scalar In1	Input scaling factor for pump 1	R/W	0
AV-37	P-1 VFD Scalar In2	Input scaling factor for pump 1	R/W	100
AV-38	P-1 VFD Scalar Out1	Output scaling factor for pump 1	R/W	0%
AV-39	P-1 VFD Scalar Out2	Output scaling factor for pump 1	R/W	100%
AV-40	P-2 VFD Scalar In1	Input scaling factor for pump 2	R/W	0
AV-41	P-2 VFD Scalar In2	Input scaling factor for pump 2	R/W	100
AV-42	P-2 VFD Scalar Out1	Output scaling factor for pump 2	R/W	0%
AV-43	P-2 VFD Scalar Out2	Output scaling factor for pump 2	R/W	100%
AV-44	KI SP	KI tuning SP for Pump Speed	R/W	1
AV-45	Custom Cycle Time (Hrs)	Setpoint for custom runtime switch hours	R	336 hours
AV-46	P-1 Runtime (Hrs)	Current P-1 runtime hours	R	0 hrs
AV-47	P-2 Runtime (Hrs)	Current P-2 runtime hours	R	0 hrs
AV-48	Pump Cycle Time (Hrs)	Current runtime hours cycle time	R	336 hrs
AV-49	KP SP	KP tuning SP for Pump Speed	R/W	.5
AV-50	P-1 Lo Amps Alarm SP	P-1 pump amps below this setpoint will trigger the Lo Amp Alarm (BV-30)	R/W	1.0 amps
AV-51	P-1 Hi Amps Alarm SP	P-1 pump amps above this setpoint will trigger the Lo Amp Alarm (BV-31)	R/W	10.0 amps
AV-52	P-2 Lo Amps Alarm SP	P-2 pump amps below this setpoint will trigger the Lo Amp Alarm (BV-35)	R/W	1.0 amps
AV-53	P-2 Hi Amps Alarm SP	P-2 pump amps above this setpoint will trigger the Lo Amp Alarm (BV-36)	R/W	10.0 amps
AV-54	Analog Value 054			
AV-55	Core Water Pressure SP	Water pressure setpoint used to determine the modulating signal to control the VFD commands	R/W	1.5"
AV-56	Analog Value 056			
AV-57	Outside Air Enable	The setpoint used to enable the pumps. When the outside air is below this setpoint the pumps are enabled to run.	R/W	50.0°F
AV-58	Reserved	This point is reserved for internal thermostat use and its value cannot be changed		
AV-59	Pseudo Ave Time Base	Factor used to average the room temperature. A small number will allow the room temperature to change faster over time. A large number will cause the room temperature to change slower over time.	R	100
AV-60	Cal Offset	The calibration offset for the internal thermistor.	R	variable
AV-61	Space Alarm Offset	This offset +/- the Current Cooling/Heating SP is used to determine if the space is too warm/cold, and set an alarm if necessary.	R/W	5.0°F
AV-62	Analog Value 062		R/W	0
AV-63	Analog Value 063		R	4
AV-64	Vacant Clg SP	Used in Hotel Mode. When a room is known vacant, the setpoint can be set below the unoccupied setpoint.	R/W	85.0°F
AV-65	Vacant Htg SP	Used in Hotel Mode. When a room is known vacant, the setpoint can be set below the unoccupied setpoint.	R/W	55.0°F
AV-66	Room Setpoint	The occupied room setpoint	R/W	73.0°F
AV-67	Occupied SP Hi Limit	The maximum occupied room setpoint allowed.	R/W	85.0°F
AV-68	Occupied SP Lo Limit	The minimum occupied room setpoint allowed	R/W	55.0°F
AV-69	Clg Offset	The offset from Room Setpoint used to calculate the Occupied Cooling SP	R/W	1.0°F

AV-70	Htg Offset	The offset from Room Setpoint used to calculate the Occupied Heating SP	R/W	1.0°F
AV-71	Unoccupied Clg SP	The cooling setpoint used when the thermostat is unoccupied.	R/W	80.0°F
AV-72	Unoccupied Htg SP	The heating setpoint used when the thermostat is unoccupied.	R/W	60.0°F
AV-73	After Hours Limit	The maximum hours the thermostat is allowed to run during afterhours time. Setting this will set the thermostat to occupied operation. (0-99.9 hrs)	R/W	5.0 hrs
AV-74	After Hours Timer	The current amount of afterhours time left.	R	0.0 hrs
AV-75	Reserved	This point is reserved for internal thermostat use and its value cannot be changed	R	0
AV-76	Reserved	This point is reserved for internal thermostat use and its value cannot be changed	R	0
AV-77	Reserved	This point is reserved for internal thermostat use and its value cannot be changed	R	0
AV-78	Reserved	This point is reserved for internal thermostat use and its value cannot be changed	R	0
AV-79	Reserved	This point is reserved for internal thermostat use and its value cannot be changed	R	0
AV-80	Reserved	This point is reserved for internal thermostat use and its value cannot be changed	R	0
AV-81	Reserved	This point is reserved for internal thermostat use and its value cannot be changed	R	0
AV-100	Analog Value 100	Internal thermister display descriptor. The present value is automatically transferred. The AV description holds the descriptor to display.	R	variable
AV-101	Analog Value 101	Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display.	R/W	
AV-102	Analog Value 102	Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display	R/W	
AV-103	Analog Value 103	Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display	R/W	
AV-104	Analog Value 104	Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display	R/W	
AV-105	Analog Value 105	Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display	R/W	
AV-106	Analog Value 106	Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display	R/W	
AV-107	Analog Value 107	Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display	R/W	
AV-108	Analog Value 108	Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display	R/W	
AV-109	Analog Value 109	Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display	R/W	

AV-110	Analog Value 110	Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display	R/W	
AV-111	Analog Value 111	Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display	R/W	
AV-112	Analog Value 112	Outside Air Display descriptor. Transfer the value to display to the present value. The AV description holds the descriptor to display	R/W	

Binary Inputs

Instance	Object Name	Description	Read/Write	Default
BI-0	Binary Input 00		R	
BI-1	Binary Input 01		R	
BI-2	Binary Input 02		R	
BI-3	Binary Input 03		R	
BI-4	Binary Input 04		R	
BI-5	Binary Input 05		R	

Binary Outputs

Instance	Object Name	Description	Read/Write	Default
BO-0	P-1 Command	Pump 1 Command	R/W	OFF
BO-1	P-2 Command	Pump 2 Command	R/W	OFF
BO-2	Binary Output 2		R/W	OFF
BO-3	Binary Output 3		R/W	OFF
BO-4	Binary Output 4		R/W	OFF
BO-5	Scheduled Occupied	Logical point only. Used for scheduling purposes. INACTIVE is unoccupied.	R/W	OFF

Binary Values

Instance	Object Name	Description	Read/Write	Default
BV-0	Bad Sensor Alarm	Alarm for a bad internal thermistor	R	OFF
BV-1	Binary Value 001			
BV-2	Binary Value 002			
BV-3	Binary Value 003			
BV-4	Binary Value 004			
BV-5	Core Pump Start Command	The Start Command comes from the OSA Enable or a Manual Command	R	OFF
BV-6	Binary Value 006			
BV-7	Binary Value 007			
BV-8	Binary Value 008			
BV-9	Binary Value 009			
BV-10	Program Status	Used to determine if the sequence was loaded correctly on a BACnet Restore or power up.	R	OFF
BV-11	Binary Value 011			
BV-12	Lead Pump Start Command	Shows the current Lead Pump command	R	OFF

BV-13	Lead Pump Alarm	Shows any Lead Pump alarms	R	OFF
BV-14	Lead Pump Status	Shows the current operational status of the Lead Pump	R	OFF
BV-15	Lag Pump Start Command	Shows the current Lead Pumps command	R	OFF
BV-16	Lag Pump Alarm	Shows any Lead Pump alarms	R	OFF
BV-17	Lag Pump Status	Show the current operational status of the Lead Pump	R	OFF
BV-18	Binary Value 018			
BV-19	Binary Value 019			
BV-20	Binary Value 020			
BV-21	Binary Value 021			
BV-22	Pump P-1 Status	Show the current operational status of P-1	R	OFF
BV-23	Pump P-2 Status	Show the current operational status of P-2	R	OFF
BV-24	Binary Value 024			
BV-25	Pump Alarm Reset	Reset the Lead or Lag pump alarm	R/W	OFF
BV-26	Manual Switch Lead/Lag Pumps	Manually switch P-1 and P-2 Lead/Lag status	R/W	OFF
BV-27	Runtime Switch Lead/Lag Pumps	Runtime hours is requesting a switch of P-1 and P-2 Lead/Lag status	R	OFF
BV-28	Current lead/Lag Pump	Shows the which pump is currently in Lead and Lag status	R	OFF
BV-29	Binary Value 029			
BV-30	P-1 Lo Alarm	P-1 low pump amp alarm	R	OFF
BV-31	P-1 Hi Alarm	P-1 high pump amp alarm	R	OFF
BV-32	P-1 Hi/Lo Alarm	P-1 pump amp alarm	R	OFF
BV-33	Binary Value 033			
BV-34	Binary Value 034			
BV-35	P-2 Lo Alarm	P-2 low pump amp alarm	R	OFF
BV-36	P-2 Hi Alarm	P-2 high pump amp alarm	R	OFF
BV-37	P-2 Hi/Lo Alarm	P-2 pump amp alarm	R	OFF
BV-38	Binary Value 038			
BV-39	Binary Value 039			
BV-40	Occupied Status	The status of this point switches the thermostats occupancy settings. ON when the thermostat is in Occupied Setpoint Mode or After Hours Mode.	R	OFF
BV-41	Opt. Start Warmup	A Warmup command has been sent to the thermostat. When ON the thermostat will switch to occupied settings.	R/W	OFF
BV-42	Opt. Start Cooldown	A Cooldown command has been sent to the thermostat. When ON the thermostat will switch to occupied settings.	R/W	OFF
BV-43	Occ Set point Mode	The thermostat has been commanded occupied via BO-5, or a Warmup/Cooldown command has been sent via BV-41/BV-42.	R	OFF
BV-44	After Hours Status	The thermostat has been set to after hours mode. When ON the thermostat will switch to occupied settings.	R	OFF
BV-45	Reserved	This point is reserved for internal thermostat use and its value cannot be changed		OFF
BV-46	P-1 VFD Run	P-1 VFD enable command	R	OFF
BV-47	P-2 VFD Run	P-2 VFD enable command	R	OFF
BV-48	Binary Value 048			

BV-49	Update Descriptors	When ON descriptor changes are sent to the thermostats LCD, this point will auto reset to OFF.	R/W	OFF
BV-50	Manual Enable Pumps	Manual Command to start pumps. The pumps will run continuously with this set to ACTIVE	R/W	OFF
BV-51	Reserved	This point is reserved for internal thermostat use and its value cannot be changed		OFF
BV-52	Sup/Ret Pres. Enable	Enable When Using 2 Pressure Sensors(Supply AI-2 & Return Ai-5) for Differential Pressure Calculation	R/W	OFF
BV-53	Binary Value 053			
BV-54	Binary Value 054			
BV-55	Binary Value 055			
BV-56	Binary Value 056			
BV-57	Disable Splash	When ACTIVE, the "EXACTLOGIC" splash will not show after key presses	R/W	OFF
BV-58	Disable Setup Menu	When ACTIVE, there will be no access to the Setup Menu where the Network/MAC/Baud Rate is set	R/W	OFF
BV-59	Disable FSM Menu	When ACTIVE, there will be not access to the Field Service Mode where the Time/Schedule/Point Access is set	R/W	OFF
BV-60	Cycle Time Enable - Day	Enable the runtime pump switch for one day	R/W	OFF
BV-61	Cycle Time Enable - Week	Enable the runtime pump switch for one week	R/W	OFF
BV-62	Cycle Time Enable - Month	Enable the runtime pump switch for one month (30 days)	R/W	OFF
BV-63	Cycle Time Enable - Custom	Enable the runtime pump switch for a custom configured amount of hours	R/W	OFF
BV-64	Reserved	This point is reserved for internal thermostat use and its value cannot be changed		OFF
BV-65	Binary Value 065			
BV-66	Disable Core Pumps	When ON this point will disable and lockout all analog and binary outputs.	R/W	OFF
BV-67	Room Temp Select	When OFF, the internal thermistor is selected for the control sequence. When ON, an external thermistor attached to AI-1 is selected for control of the sequence	R/W	OFF
BV-68	Backlight Off/On	When ON the LCD backlight will remain on	R/W	OFF
BV-69	Reserved	This point is reserved for internal thermostat use and its value cannot be changed		OFF
BV-70	Reserved	This point is reserved for internal thermostat use and its value cannot be changed		OFF
BV-71	C/F	Sets the thermostat to display temperatures in Celsius or Fahrenheit. This point is set through the setup menu. ON = F, OFF = C	R	ON
BV-72	Binary Value 072			
BV-73	Binary Value 073			
BV-74	Hotel Mode	Determines how the thermostats occupancy is set. OFF = RTU Mode, ie schedule ON = Hotel Mode, ie motion sensors	R/W	OFF
BV-100	Binary Value 100	Enable internal thermister descriptor	R/W	ON
BV-101	Binary Value 101	Enable descriptor	R/W	OFF

BV-102	Binary Value 102	Enable descriptor	R/W	OFF
BV-103	Binary Value 103	Enable descriptor	R/W	OFF
BV-104	Binary Value 104	Enable descriptor	R/W	OFF
BV-105	Binary Value 105	Enable descriptor	R/W	OFF
BV-106	Binary Value 106	Enable descriptor	R/W	OFF
BV-107	Binary Value 107	Enable descriptor	R/W	OFF
BV-108	Binary Value 108	Enable descriptor	R/W	OFF
BV-109	Binary Value 109	Enable descriptor	R/W	OFF
BV-110	Binary Value 110	Enable descriptor	R/W	OFF
BV-111	Binary Value 111	Enable descriptor	R/W	OFF
BV-112	Binary Value 112	Enable outside air descriptor	R/W	OFF